
FTdx3000d – ANT3 as RX ANT PROTECTED FOR BEWERAGE or LNA AMPLIFIER



I had also already checked with a simple tester (checking on the service manual):

ANT1/1 rx or tx ===> RX ANT3 GROUNDET (0) ANT2/2 rx or tx ===> RX ANT3 GROUNDET (0)

ANT3 ===> DURING TX AS RX3/1 or RX3/2 the ANT3 GROUNDET (0)

MENU 032 ANT3:

The ANT3 jack enables to use an antenna for reception only. Using MENU 032 ANT3 SETTING for switch: ANT3/1 or ANT3/2 to save PREAMP LNB as RF ground protection

---Original Yaesu info---

[...]The antenna ports are connected to ground through a relay when inactive so the isolation is very good. You shouldn't have any problem.

Best Regards, Jerry Darby, N6UME Amateur Tech Support Amateur Products Division Yaesu USA

Franco, hb9oab

-.-.-.-.-.-.

FreeWare FTdx3000d library online at: http://hb9oab.no-ip.org/ftdx3000d